


Technical Service Information



8

Technical Service Information

When Checked: Continuously when transaxle is in gear.

Effect:

Transaxle limp-in (2nd gear).

Note: Errors in speed data are tolerated for some time before going into limp-in. However, once an error is detected, this sequence of events will be followed:

- Shifts are inhibited.
- Lock up operation is inhibited.
- Solenoid circuits are tested and, if they fail, are blamed for the speeds error.
- Limp-In (2nd gear).

Probable Causes:

Probable Causes	Speed Error Code						
	50	51	52	53	54	55	56
Open/shorted SG1 circuit	X	X					
Defective Output Sensor	X	X					
Output Sensor Connector Problem	X	X					
60-way Connector Problem							
Cavity 13	X	X					
Cavity 14	X	X					
Cavity 52	X	X					
Open/shorted ST1 circuit	X	X					
Defective Turbine Sensor	X	X					
Turbine Sensor Connector Problem	X	X					
Open SG5 circuit (Sensors Ground)							X
Internal Controller Failure	X	X				X	X
Internal Transaxle Problem	X	X	X	X	X		

Note: Code 55 will not be seen in 1991. It is reserved for future use.



Technical Service Information



1

Technical Service Information

Diagnosis and Tests

AGNOSIS—GENERAL

NOTION: Before attempting any repair on the A-604 automatic Automatic Transaxle, always check for fault codes with the DRBI using the "Powertrain Diagnostic Test Procedure Manual (A-504)".

Automatic transaxle malfunctions may be caused by four general conditions: poor engine performance, improper adjustments, hydraulic malfunctions, mechanical malfunctions, and electronic malfunctions. Diagnosis of these problems will always begin by checking the easily accessible variables: fluid level and condition, gearshift cable adjustment. Then perform a road test to determine if the problem has been corrected.

MICROWAREHOUSE that more diagnosis is necessary. If the problem exists after the preliminary tests and corrections are completed, hydraulic pressure checks should be performed.

Mid Level and Condition

Oil transmission and differential sums have a common sump with a communicating opening between the two. Once this torque converter fills in both the Park and "N" Neutral positions, place the selector lever in "P" Park to be sure that the fluid level check is accurate. The engine should run at idle speed for at least one minute, with vehicle on level ground. This will assure complete oil level stabilization between differential and transmission. The fluid should be at normal operating temperature (approximately 82°C or 180°F).

Fluid level is correct if it is in the "HOT" on (cross-hatched area) on the oil level indicator. Fluid level can cause a variety of conditions because it allows the pump to take in air bubbles with the fluid. As in any hydraulic system, bubbles make the fluid sponge; therefore, bubbles will be low and build up slowly.

Proper filling can also raise the fluid level high. When the transaxle has too much fluid, gears churn up foam and cause the same conditions which occur with a low fluid level. Either case, the air bubbles can cause over-heating, fluid oxidation, and varnishing, which

can interfere with normal valve, clutch, and accumulator operation. Foaming can also result in fluid escaping from the transaxle vent where it may be mistaken for a leak.

Along with fluid level, it is important to check the condition of the fluid. When the fluid smells burned, and is contaminated with metal or friction material particles, a complete transaxle overhaul is needed. Be sure to examine the fluid on the dipstick closely. If there is any doubt about its condition, drain out a sample for a double check.

After the fluid has been checked, seat the dipstick fully to seal out water and dirt.

Gearshift Linkage

Normal operation of the PRNDL and neutral safety switch provides a quick check to confirm proper manual linkage adjustment.

Move the selector lever slowly upward until it clicks into the "P" Park notch in the selector gate. If the starter will operate the "P" position is correct.

After checking "P" position move the selector slowly toward "N" Neutral position until lever drops at the end of the "N" stop in the selector gate. If the starter will also operate at this point the gearshift linkage is properly adjusted. If adjustment is required, refer to gearshift linkage adjustment in Maintenance and Adjustments and refer to DRBI in the "Diagnostic Test Procedure Manual."

Road Test

Prior to performing a road test, be certain that the fluid level and condition, and control cable adjustment have been checked and approved.

During the road test, the transaxle should be operated in each position to check for slipping and any variation in shifting.

In most cases, the clutch that is slipping can be determined by noting the transaxle operation in all selector positions and by comparing which internal units are applied in those positions. The "Elements In Use Chart" provides a basis for road test analysis.

The process of eliminating can be used to de-

Code 47:

To Set Code:

Conditions

- In partial or full lock up.
- Two back to back occurrences of LR pressure build up.

When Checked:

Effect:

Probable Causes:

Continuously when doing partial or full lock up.

Transaxle limp-in (2nd gear).

Probable Causes:

- Internal transaxle problem.

The solenoid switch valve (SSV) controls the direction of the transmission fluid when the LRLU solenoid is energized. The SSV will be in the down shifted position in 1st gear, thus directing the fluid to the LR element. In 2nd, 3rd and 4th, it will be in the upshifted position and directs the fluid into the lockup switch valve which controls torque converter lockup.

When doing partial lockup (PL) or full lockup (FL), the LR pressure switch should indicate no pressure if SSV is in the LU position. If LR pressure switch indicates pressure for some time while in PL or FL, lockup operation is aborted and inhibited to avoid inadvertent application of the LR clutch.



Technical Service Information




Fig. 1—Pressure Taps

Test One {Selector in L—1st gear}

- (1) Attach pressure gauge to the low/reverse clutch tap.
- (2) Move selector lever to the L position.
- (3) Allow vehicle wheels to turn and increase throttle opening to achieve an indicated vehicle speed to 20 mph.
- (4) Low/reverse clutch pressure should read 115 to 145 psi.
- (5) This test checks pump output, pressure regulation and condition of the low/reverse clutch hydraulic circuit and shift schedule.

Test Two {Selector in D—2nd gear}

- (1) Attach gauge to the underdrive clutch tap.
- (2) Move selector lever to the D position.
- (3) Allow vehicle wheels to turn and increase throttle opening to achieve an indicated vehicle speed of 30 mph.
- (4) Underdrive clutch pressure should read 110 to 145 psi.
- (5) This test checks the underdrive clutch hydraulic circuit as well as the shift schedule.

Test Three {Overdrive clutch check}

- (1) Attach Gauge to the overdrive clutch tap.
- (2) Move selector lever to the circle D position.
- (3) Allow vehicle wheels to turn and increase throttle opening to achieve an indicated vehicle speed of 20 mph.
- (4) Overdrive clutch pressure should read 74 to 95 psi.
- (5) Move selector lever to the D position and increase indicated vehicle speed to 30 mph.
- (6) The vehicle should be in second gear and overdrive clutch pressure should be less than 5 psi.
- (7) This test checks the overdrive clutch hydraulic circuit as well as the shift schedule.



Technical Service Information

Code 45:

Internal A-604 Controller (EEPROM Memory Failure)

Background:

The A-604 transmission system supports several engine models, each requiring different shift schedule and calibration constants. The EATX controller receives the engine model code from the engine controller and stores it in the microprocessor's EEPROM memory. Once the engine model code is established in the EEPROM memory, it is used thereafter to select the appropriate shift schedule and other calibrations.

The EEPROM memory location used for the engine model code is checked to verify its ability to hold data. If this EEPROM memory location fails the checks, the code is set.

**Conditions
To Set Code:**

- A new transaxle controller is installed.
- C3D bus is operational.
- The EEPROM memory location used to store engine model fails the checks (data read from it doesn't match data written to it).

When Checked:

After a reset (ignition key turned to the RUN position or after cranking engine).

Effect:

No limp-in.

Probable Causes: Internal controller failure.

Test Result Indications

- (1) If proper line pressure is found in any one test, the pump and pressure regulator are working properly.
- (2) Low pressure in all positions indicates a defective pump, a clogged filter, or a stuck pressure regulator valve.
- (3) Clutch circuit leaks are indicated if pressures do not fall within the specified pressure range.
- (4) If the overdrive clutch pressure is greater than 5 psi in step 6 of Test Three, a worn reaction shaft seal ring is indicated.



Technical Service Information

DEFAULT CODE CHART "A"

Condition	Low fluid level	Aerated fluid (high fluid level)	Worn or damaged reaction shaft support seal rings	Worn or damaged input shaft seal rings	Worn pump	Damage or failed clutches:	UD clutch	OD clutch	Reverse clutch	2/4 clutch	L/R clutch	Damaged clutch seats	Worn or damaged accumulator seal rings	Plugged filter	Stuck/stick valves	Solenoid switch valve	Lockup switch valve	Torque converter control valve	Regulator valve	Valve body leakage	Pressures too high	Internal solenoid leak	Torque converter lockup clutch failure	Fairly cooling system	Damaged speed sensor gear teeth	Planetary gears/sets broken or seized
21 OD clutch—Pressure too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
22 2/4 clutch—Pressure too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
23 2/4 clutch and OD clutch—Pressures too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
24 L/R clutch—Pressure too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
25 L/R clutch and OD clutch—pressures too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
26 L/R clutch and 2/4 clutch—pressures too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
27 OD, 2/4, and L/R clutches—pressures too low	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
31 OD clutch pressure switch response failure	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
32 2/4 pressure switch response failure	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
33 2/4 and OD clutch pressure response failures	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
37 Solenoid switch valve failure	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
38 Partial lockup control out of range	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
39 Speed ratio default	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		

Conditions To Set Code:

- Lock up conditions are met.
- The torque converter fails to lock up within the allowed time.
- Throttle less than 30 degrees.

Note: The general requirements for torque converter lock up are:

- Normal operating or high temperature.
- Brake is released.
- Throttle within proper range.

- No speed, pressure switch or throttle data error.

- Minimum vehicle speed which is a function of Shift Lever Position, gear, and engine temperature (e.g. 46 mph with Shift Lever in OD and 4th gear).

- No Solenoid Switch Valve problem detected.

When Checked: When in partial lock up (PL).

Effect: - No limp-in
- Lock up operation is inhibited.

Probable Causes: - Low/high transaxle fluid.
- Internal transaxle problem.


Code 39: Gear ratio error for 89/90. For 91 code 39 has been broken down into codes 50-58. Refer to fault codes 50 through 58 for gear ratio fault code explanations and probable causes.



AUTOMATIC TRANSMISSION SERVICE GROUP



Technical Service Information



16



Code 36: Fault Immediately After Shift (1991)

Background:

This code is not stored alone. It is stored if a speed error (codes 50 through 58) is detected immediately after a shift.

The existence of code 36 indicates a mechanical or hydraulic (non-electrical) related problems. It should be noted, however, that all mechanical problems don't necessarily result in code 36.

When this code exists, diagnosing the system should be based on the associated code and ONLY mechanical causes should be considered first.


Conditions

To Set Code: Speed Error detected immediately after a shift.

When Checked: Speed Error code is stored.

Effect: Same as the associated code.

Probable Causes: Internal transaxle problem (refer to Speed Errors).



18

Code 29: Throttle Position Signal
Background:

The EATX controller receives the throttle signal (K7 circuit) and its ground (N5 circuit) from the Throttle Position Sensor (TPS). The TPS has a 5 volt pull up (KB circuit) supplied by the engine controller. The throttle signal is checked for out-of-range as well as intermittency (excessive signal changes).


- Conditions To Set Code:**
- Throttle signal out-of range.


- When Checked:** Continuously.

- Effect:**
- No limp-in.
- A default throttle value is used.
- No lockup.
- No 4th gear.
- Limited shift schedule.
- Earlier coastdown shifts (i.e. at higher speeds).

Probable Causes:

- Open/shorted K7 circuit.
- Open N5 circuit.
- Open KB between TPS and engine controller.
- 60-way connector problem.
- Defective TPS.
- Defective engine controller.
- Internal controller failure.





Code 28:

Check PRNDL Signal

Background:

PRNDL and Neutral/Start (NS/S) switches are used to:

1. Determine the Shift Lever Position (SLP).
 2. Supply a ground to the Starter Relay in Park and Neutral only.
 3. Supply a ground to the Backup Lamp Relay in Reverse only.
- The controller reads the switch signals (NS1 and RL1 from Neutral/Start switch, NS2 and RL2 from PRNDL switch) according to the table below which includes two recognized temporary codes that occur while moving SLP.

Normal PRNDL & Neutral/Start Switch States

SLP	NS2	NS1	RL2	RL1
P	1	1	0	0
R	0	0	1	1
N	0	1	1	0
OD	0	0	0	1
D	0	0	1	0
L	1	0	0	0
T1	1	0	0	0
T2	0	0	0	0

0 = Switch is open

1 = Switch is closed


When an invalid code is seen, the controller tries to determine SLP through hydraulic interpretation (by energizing some solenoids and monitoring the pressure switch responses).

Conditions To Set Code:	An invalid SLP code is seen for a few seconds.
When Checked:	Continuously.
Effect:	No limp-in. However, valid but incorrect PRNDL and Neutral/Start signals, (e.g. shift lever is in OD position where R code is being received), may result in other fault codes and possibly a limp-in.

This is why it is very important to verify the correctness of the SLP signals before diagnosing any problems.



Technical Service Information



Background:

The A604 transaxle system uses three pressure switches to monitor the fluid pressure in the LR, 24, and OD elements. The pressure switches are continuously checked for the correct states in each gear as indicated below:

Normal Pressure Switch States

GEAR	LR	24	OD
P	1	0	0
R	0	0	0
N	1	0	0
1ST	1	0	0
2ND	0	1	0
3RD	0	0	1
4TH	0	1	1

- 0 = Switch is open
1 = Switch is closed

When a pressure switch mismatch is detected, the solenoid circuits are tested for continuity. If that test fails, solenoid circuits are blamed for the pressure switches mismatch. Otherwise the appropriate pressure switch code is set.

The pressure switch states are checked when:

- Engine has been running for at least a few seconds.
- Correct Transaxle fluid level.
- Transaxle is in gear.
- Pressure switch mismatch.

When Checked:

Continuously.

Effect:

Transaxle limp-in (2nd gear).



Technical Service Information


Code 21 to 27: Pressure Switch Circuits

Code 21	OD Pressure Switch Circuit
Code 22	24 Pressure Switch Circuit
Code 23	24 & OD Pressure Switch Circuits
Code 24	LR Pressure Switch Circuit
Code 25	LR & OD Pressure Switch Circuits
Code 26	LR & 24 Pressure Switch Circuits
Code 27	All Pressure Switch Circuits

Technical Service Information



Technical Service Information

**Code 19: C²D Bus Communication****Background:**

EATX communicates with the engine controller over the C²D bus. Engine RPM, Engine and Ambient Temperature are among the information received by EATX. The controller continuously monitors the bus activity and receives the messages it needs.

Conditions To Set Code:

No activity on the C²D bus.

When Checked:

Continuously.

Effect:

- No limp-in.


- Due to loss of temperature information:

- a. Delayed 3-4 shift and early 4-3 shift for few minutes after engine is started.
- b. No lock up operations for a few minutes after engine is started.


NOTE: When the C²D bus becomes operational again, EATX will resume receiving the needed messages. However, the code will remain set.

Probable Causes:

- Open MX1 or MX2 circuits between EATX and engine controller.
- Shorted MX1 or MX2 circuit.
- C²D bus biasing problem (bus has to be properly biased by one of the vehicle's controllers).
- Engine controller C²D problem circuit.
- EATX controller C²D circuit problem.



Technical Service Information



26



Technical Service Information

Code 18: Internal A-504 Control (ROM Check failure)**Background:**

When the controller is reset, the CPU checks the integrity of the program memory (ROM). It adds all used bytes in the program memory. The sum should be the same as a known constant (stored in program memory).

Conditions

ROM checksum does not match a known constant.

To Set Code:

After a reset (ignition key turned to the RUN position or after cranking engine).

Effect:

Transaxle limp-in (2nd Gear).

Probable Causes: Internal controller failure.**Code 17: Internal A-504 Controller (RAM Check Failure)****Background:**

When the controller is reset, the CPU checks the integrity of each RAM location by writing to it and reading back from it. The read value should be the same as value written.

Conditions**To Set Code:**

Data read from at least one RAM location does not match data written to it.

When Checked: After a reset (ignition key turned to the RUN position or after cranking engine).**Effect:**

Transaxle limp-in (2nd gear).

Probable Causes: Internal controller failure.



Technical Service Information




Fig. 3—Testing Reverse Clutch

Reverse Clutch

Apply air pressure to the reverse clutch apply passage and watch for the push/pull piston to move rearward. The piston should return to its starting position when the air pressure is removed.

24 Clutch

Apply air pressure to the feed hole located on the 24 clutch retainer. Look in the area where the 24 piston contacts the first separator plate and watch carefully for the 24 piston to move rearward. The piston should return to its original position after the air pressure is removed.

Low/Reverse Clutch

Apply air pressure to the low/reverse clutch feed hole (rear of case, between 2 bolt holes). Then, look in the area where the low/reverse piston contacts the first separator plate and watch carefully for the piston to move forward. The piston should return to its original position after the air pressure is removed.




Fig. 4—Leak Locating Test Probe Tool

Leakage Test Probe

(1) Remove torque converter housing dust shield.

(2) Clean the inside of torque converter housing (lower area) as dry as possible. A solvent spray followed by compressed air drying is preferable.

(3) Fabricate and fasten test probe (FIG. 4) securely to convenient dust shield bolt hole. Make certain torque converter is cleared by test probe. Tool must be clean and dry.

(4) Run engine at approximately 2,500 rpm with transaxle in neutral, for about 2 minutes. Transaxle must be at operating temperature.

(5) Stop engine and carefully remove tool.

FLUID LEAKAGE—TRANSAXLE TORQUE CONVERTER HOUSING AREA

(1) Check for Source of Leakage.

Since fluid leakage at or around the torque converter area may originate from an engine oil leak, the area should be examined closely. Factory fill fluid is dyed red and, therefore, can be distinguished from engine oil.

(2) Prior to removing the transaxle, perform the following checks:

When leakage is determined to originate from the transaxle, check fluid level prior to removal of the transaxle and torque converter.

High oil level can result in oil leakage out the vent in the manual shaft. If the fluid level is high, adjust to proper level.

After performing this operation, inspect for leakage. If a leak persists, perform the following torque converter or transaxle that is leaking.

Code 15: EATX Relay Always Off

Background:

The EATX relay is used to supply power to the solenoid pack (when in normal operating mode) and to turn off power (when the transaxle is in "Jump-in" mode). The relay output (which supplies power to the solenoid pack) is fed back to the controller through pins 16 and 17. It is referred to as SWITCHED BATTERY.

After a controller reset (ignition key turned to the RUN position or when cranking engine), the controller energizes the relay. Then the controller verifies that the relay contacts are closed by checking for voltage on SWITCHED battery (i.e. relay output).


Conditions To Set Code: Relay output (Switched Battery) has less than 3 volts when relay is energized by controller.
Effect: Transaxle limp-in (2nd gear).

Probable Causes:

- Relay failure (Open contacts).
- Short to ground in S41 circuit.
- Open S41 circuit between relay and controller.
- Open J91 circuit from relay to ground.
- Open J11 circuit from relay to splice.
- 60-way connector Problem (cavities 15, 16, and 17).
- Internal controller failure.



Technical Service Information



Technical Service Information

Code #13:

Internal A-604 Controller (Watchdog Circuit Shutdown)

Background:

The internal Watchdog (WD) circuit continuously monitors the CPU. It provides a shutdown function when it detects a problem in the CPU.

Conditions To Set Code: A problem with the microprocessor detected by WD.

When Checked: After a reset/ignition key turned to the RUN position or after cranking engine, and periodically thereafter.

Effect: Transaxle limp-in (2nd gear).

Probable Causes: Internal controller failure.

Code 14: EATX Relay Always On

Background: The EATX relay is used to supply power to the solenoid pack (when in normal operating mode) and to turn off power (when the transaxle has been placed into the "limp-in" mode of operation). The relay output (which supplies power to the solenoid pack) is fed back to the controller through pins 16 and 17. It is referred to as SWITCHED BATTERY.

After a controller reset (ignition key turned to the RUN position or after cranking engine), the controller energizes the relay. But before this is done, the controller verifies that the relay contacts are open by checking for no voltage on switched battery (i.e. relay output).

Conditions To Set Code: Relay output (Switched Battery) has more than 3 volts when relay is not energized by controller.

When Checked: After a reset (ignition key turned to the RUN position or after cranking engine), and after a "power-down" from turning ignition off.

Effect: Transaxle limp-in (2nd gear).

Probable Causes: - Relay failure (Welded contacts).

- Short to battery in SA1 circuit.
- Short to battery in SF1 circuit.
- 60-way connector problem (cavities 15, 16, and 17).
- Internal controller failure.



Technical Service Information



Technical Service Information

POSSIBLE CAUSE	DIAGNOSIS CHART "B"									
	WORN OR FAULTY CLUTCHES		UNDERDRIVE CLUTCH		OVERDRIVE CLUTCH		REVERSE CLUTCH		2/4 CLUTCH	
Worn or damaged gearshift seal ring(s)	X	X	X	X	X	X	X	X	X	X
Low/reverse clutch	X	X	X	X	X	X	X	X	X	X
Clutch(es), dragging	X	X	X	X	X	X	X	X	X	X
Insufficient clutch plate clearance			X	X	X					
Damaged clutch seals			X	X	X					
Worn or damaged accumulator seal ring(s)	X	X	X	X	X	X	X	X	X	X
Faulty cooling system										
Engine coolant temp. too low										
Incorrect gearshift control										
Linkage adjustment										
Shift linkage damaged										
Chipped or damaged gear teeth										
Planetary gears/bearings broken or seized										
Bearings worn or damaged										
Driveshaft(s) bushing(s) worn or damaged										
Horn or broken reaction shaft support seal rings	X	X	X	X	X	X	X	X	X	X
Worn or damaged input shaft seal rings	X	X	X	X	X	X	X	X	X	X
Wave body malfunction or leakage	X	X	X	X	X	X	X	X	X	X
Hydraulic pressures too low	X	X	X	X	X	X	X	X	X	X
Hydraulic pressures too high	X	X	X	X	X	X	X	X	X	X
Aerated fluid										
Faulty oil pump										
Oil filter clogged										
Low fluid level										
High fluid level										
HARD TO FILL, OIL BLOWS OUT FILLER TUBE										
TRANSAXLE OVERHEATS										
HARSH UPSHIFT										
NO UPSHIFT INTO OVERDRIVE										
NO LOCKUP										
HARSH DOWNSHIFTS										
HIGH SHIFT EFFORTS										
HARSH LOCKUP SHIFT										
BUZZING NOISE DURING SHIFTS ONLY										
HARSH ENGAGEMENT FROM NEUTRAL TO D R										
DELAYED ENGAGEMENT FROM NEUTRAL TO D R										
POOR SHIFT QUALITY SHIFTS ERRATIC										
DRIVES IN NEUTRAL DRAGS OR LOCKS										
GRATING, SCRAPING, GROWLING NOISE										
KNOCKING, NOISE BUZZING NOISE										
BUZZING NOISE DURING SHIFTS ONLY										
HARD TO FILL, OIL BLOWS OUT FILLER TUBE										
TRANSAXLE OVERHEATS										
HARSH UPSHIFT										
NO UPSHIFT INTO OVERDRIVE										
NO LOCKUP										
HARSH DOWNSHIFTS										
HIGH SHIFT EFFORTS										
HARSH LOCKUP SHIFT										

CONDITION	CHRYSLER A604 DIAGNOSTIC FAULT CODE CHART										
	CODE		LIMP-IN								
INTERNAL A604 CONTROLLER	11	YES	INTERNAL A604 CONTROLLER	12	NO	BATTERY WAS DISCONNECTED	13	YES	INTERNAL A604 CONTROLLER	14	YES
BATTERY			BATTERY RELAY OUTPUT ALWAYS ON			EATX RELAY OUTPUT ALWAYS ON			EATX RELAY OUTPUT ALWAYS ON		
INTERNAL A604 CONTROLLER	15	YES	INTERNAL A604 CONTROLLER	16	YES	INTERNAL A604 CONTROLLER	17	YES	INTERNAL A604 CONTROLLER	18	YES
INTERNAL A604 CONTROLLER	19	NO	SWITCHED BATTERY	20	YES	SWITCHED BATTERY	21	YES	SWITCHED BATTERY	22	YES
OD PRESSURE SWITCH CIRCUIT	23	YES	OD PRESSURE SWITCH CIRCUIT	24	YES	L/R AND OD PRESSURE SWITCH CIRCUITS	25	YES	L/R AND OD PRESSURE SWITCH CIRCUITS	26	YES
OD PRESSURE SWITCH CIRCUIT	27	YES	2/4 PRESSURE SWITCH CIRCUIT	28	NO	2/4 AND OD PRESSURE SWITCH CIRCUITS	29	NO	2/4 AND OD PRESSURE SWITCH CIRCUITS	30	NO
ALL PRESSURE SWITCH CIRCUITS	31	YES	CHECK PEDAL SIGNAL	32	YES	OD AND 2/4 HYDRAULIC PRESSURE SWITCH	33	YES	OD AND 2/4 HYDRAULIC PRESSURE SWITCH	34	YES
CHECK PEDAL SIGNAL	35	NO	2/4 HYDRAULIC PRESSURE SWITCH	36	YES	FAULT IMMEDIATELY AFTER SHIFT	37	NO	LOCKUP CONTROL	38	NO
OD HYDRAULIC PRESSURE SWITCH	39	YES	OD HYDRAULIC PRESSURE SWITCH	40	YES	INTERNAL A604 CONTROLLER	41	YES	INTERNAL A604 CONTROLLER	42	YES
OD SOLENOID CIRCUIT ERROR	43	YES	OD SOLENOID CIRCUIT ERROR	44	YES	INTERNAL A604 CONTROLLER	45	NO	INTERNAL A604 CONTROLLER	46	NO
UD SOLENOID CIRCUIT ERROR	47	YES	UD SOLENOID CIRCUIT ERROR	48	YES	INTERNAL A604 CONTROLLER	49	NO	INTERNAL A604 CONTROLLER	50	YES
INTERNAL A604 CONTROLLER	51	YES	3-4 SHIFT ABORT	52	YES	INTERNAL A604 CONTROLLER	53	YES	INTERNAL A604 CONTROLLER	54	YES
SOLENOID SWITCH VALVE (STUCK IN L/R POSITION)	55	YES	GEAR RATIO ERROR IN REVERSE	56	YES	INTERNAL A604 CONTROLLER	57	YES	INTERNAL A604 CONTROLLER	58	YES
GEAR RATIO ERROR IN 1ST	59	YES	GEAR RATIO ERROR IN 1ST	60	NO	GEAR RATIO ERROR IN 1ST	61	NO	GEAR RATIO ERROR IN 1ST	62	NO
GEAR RATIO ERROR IN 2ND	63	YES	GEAR RATIO ERROR IN 2ND	64	NO	GEAR RATIO ERROR IN 2ND	65	NO	GEAR RATIO ERROR IN 2ND	66	NO
GEAR RATIO ERROR IN 3RD	67	YES	GEAR RATIO ERROR IN 3RD	68	NO	GEAR RATIO ERROR IN 3RD	69	NO	GEAR RATIO ERROR IN 3RD	70	NO
GEAR RATIO ERROR IN 4TH	71	YES	GEAR RATIO ERROR IN 4TH	72	NO	GEAR RATIO ERROR IN 4TH	73	NO	GEAR RATIO ERROR IN 4TH	74	NO
TURBINE SENSOR ERROR	75	YES	TURBINE SENSOR ERROR	76	NO	OUTPUT SENSOR ERROR	77	YES	OUTPUT SENSOR ERROR	78	NO
SENSORS GROUND ERROR	79	YES	SENSORS GROUND ERROR	80	NO	TRADEQUATE L/R ELEMENT VOLUME	81	YES	TRADEQUATE L/R ELEMENT VOLUME	82	NO
INADEQUATE L/R ELEMENT VOLUME	83	NO	INADEQUATE L/R ELEMENT VOLUME	84	NO	INADEQUATE UD ELEMENT VOLUME	85	NO	INADEQUATE UD ELEMENT VOLUME	86	NO
INADEQUATE UD ELEMENT VOLUME	87	NO	*	*DENOTES NEW FOR 1991							



Technical Service Information



Technical Service Information

new grommet into lever and rod into grommet.

- CAUTION: Set parking brake.**
- (1) Place gearshift lever in "P" (PARK) position.
 - (2) Loosen clamp bolt on gearshift cable bracket.
 - (3) Column shift. Insure that pre-tension adjustment spring engages fork on transaxle bracket.
 - (4) Pull the shift lever by hand all the way to the front detent position (PARK) and tighten lock screw to 11 N·m (100 in. lbs.). Gearshift linkage should now be properly adjusted.

SERVICE IN VEHICLE

- (5) Check adjustment as follows:
 - (a) Detent position for neutral and drive should be within limits of hand lever gate stops.
 - (b) Key start must occur only when shift lever is in park or neutral positions.
- (6) To remove button assembly, completely remove knob attaching fasteners. Pull knob "up" sharply. Proceed as outlined in console removal, "Group 23."
- After console is back in place, install knob and button by reversing the above procedure.




Figure 3

WAREHOUSE

GENERAL INFORMATION

Various transaxle components can be removed for repairs without removing the transaxle from the vehicle. The removal, reconditioning, and installation procedures for some of these components are covered here.

The valve body (see service out of vehicle) may be serviced in the vehicle, as can the parking spray, solenoid assembly, PARK/Switch, Neutral/Safety switch, and extension housing oil seal.

SPEEDOMETER PINION GEAR

When the speedometer pinion adapter is removed for any reason, a NEW O-ring must be installed on its outside diameter of the adapter.

Remove and Install

- (1) Remove bolt and washer assembly securing speedometer pinion adapter in the extension housing.
- (2) With cable housing connected, carefully work adapter and pinion out of the extension housing.
- (3) Remove the retainer and remove the pin. If transmission fluid is found in cable housing, install a new speedometer pinion and seal assembly.

ALUMINUM THREAD REPAIR

Damaged or worn threads in the aluminum transaxle case and valve body can be repaired by the use of Heli-Coils, or equivalent. Essentially, this repair consists of drilling out the worn-out damaged threads, tapping the hole with a special Heli-Coil tap, or equivalent, and installing a Heli-Coil insert, or equivalent, into the tapped hole. This brings the hole back to its original thread size. Heli-Coil, or equivalent, tools and inserts are readily available from most automotive parts suppliers.



Technical Service Information



TORQUEFLITE A604 UPDATED REPAIR PACKAGE

This bulletin applies to all Dynasty, New Yorker, Landau, Ram Van, Caravan, and Voyager vehicles.

There is now available from OEM a new repair package, part number 4549248, that includes a new 4 ring front pump reaction shaft (See Figure 1), and a new input clutch hub with shallower "O" ring grooves to increase the compression of the "O" rings (See Figure 3). The new 4 ring front pump reaction shaft (Figure 1) provides better sealing for the overdrive clutch, and the new input clutch hub with shallower "O" ring grooves (Figure 3) provides better sealing for both the underdrive clutch and the reverse clutch. Both of these updated parts are highly recommended to provide better durability for the A604 transaxle.

There has also been a modification to the input clutch retainer as shown in Figure 2. The "lip" can be machined off of the old style input clutch retainer, or it must be replaced with part number 4431609. Refer to Figure 2.

The new repair package also includes a new valve body spacer plate. Remove and "Discard" the old spacer plate, as the new spacer plate has a larger overdrive clutch feed orifice to provide increased oil flow to the overdrive clutch circuit. If the transmission controller part number is 5234623, or 5234649, replace it with part number 5234678 (or Subsequent) transmission controller.

During reassembly of the transaxle, select a washer to set input shaft end play to the "Preferred" setting of ".015" - ".015". The end play specification is actually ".005" - ".025" and is acceptable if the "Preferred" setting cannot be obtained.

SERVICE INFORMATION

New Repair Package.....	4549248
Gasket Package.....	4504558
Input Clutch Retainer (As Required).....	4431609
Transmission Controller (As Required).....	5234678




Fig. 1—Input Speed Sensor—Removed

Fig. 2—Solenoid Assembly




Fig. 3—Sound Cover




Fig. 4—Position Manual Valve






Fig. 5—Input Speed Sensor



38

Technical Service Information





Technical Service Information



Technical Service Information

TIGHTENING REFERENCE

Item	Thread Size	Newton-meters	Inch-Pounds	Foot-Pounds
AB04 Electronic Automatic Transaxle:				
Cooler Line Fittings				
Differential Cover				
Differential Ring Gear				
Differential Bearing Retainer				
Front End Cover				
Extension Housing				
Input Speed Sensor				
LR Clutch Retainer				
Neutral Safety Switch				
Oil Pan to Case	M8 x 1.0 x 25	12	110	—
Output Gear Bolt (1.5 inch hex)	M8 x 1.25 x 25	19	165	—
Output Speed Sensor	M8 x 1.25 x 23	28	70	21
Pressure Taps	M8 x 1.25	19	—	14
PRNDL Switch	M8 x 1.25	19	—	21
Pump to Case	M8 x 1.25	19	—	21
Reaction Shaft to Pump	M8 x 1.25	19	—	21
Solenoid Assy. to Case	M8 x 1.25	22	—	23
Transfer Plate to Case	M6 x 1.0 x 93.5	12	105	23
Transfer Gear Nut (1.25 inch hex)	M6 x 1.0	12	105	23
Valve Body & Transfer Plate	M22 x 1.5	27	105	23
Vent Assembly	M5 x 0.8	27	105	23
8-Way Solenoid Connector	M6 x 1.0	12	40	20
60-Way EATX Connector	M6 x 1.0	4	38	20




Fig. 6—Remove or Install Valve Body

Fig. 7—Valve Body Removed




Fig. 8—Manual Shaft Screw

Fig. 9—Retaining Plate Screw

Fig. 10—Transfer Plate and Separator Plate

Fig. 11—Transfer Plate



Technical Service Information

LOCKUP SWITCH VALVE

SPRING PLUG


ACCUMULATOR
PISTON
(OVERDRIVE OR
UNDERDRIVE)RETURN
SPRING

Fig. 1—Accumulators




Fig. 14—Remove or Install Dual Retainer Plate




Fig. 2—Accumulator




Fig. 3—Low/Reverse Accumulator Snap Ring

When installing valve body assembly onto transmission, observe Figure 5 and guide park rod rollers into guide bracket, while shifting manual lever assembly out of the installation position.

ACCUMULATORS




Fig. 4—Low/Reverse Accumulator Plug



Technical Service Information

A-504 4-SPEED AUTOMATIC TRANSMAXLE

SPECIFICATIONS

Type	Fully-adaptive, electronically-controlled four-speed automatic with torque converter and integral differential
Torque Converter Diameter	24.1 millimeters (9.48 inches)
Oil Capacity—Transaxle and Torque Converter	8.6 Liters (18.25 pints)
Oil Type	MOGAR ATF Type 7126 (or DEXRON II)
Cooling Method	Water heat exchanger and/or air-to-oil heat exchanger
Lubrication	Pump (internal-external gear type)
Gear Ratios:	
First	2.84
Second	1.57
Direct	1.00
Overdrive	.59
Reverse	2.21
Overall Top Gear Ratio: (in overdrive)	
Plug Clearances:	
Tapered Roller Bearing Settings:	
Output Gear	.02-.05 Preload .05-.10 End Play
Transfer Shaft	.002-.02 Preload .006-.012 End Play
Differential	

SPEEDOMETER PINIONS (MANUAL and AUTOMATIC)

The chart below applies to all front-wheel-drive vehicles equipped with Manual or Automatic Transaxles.

Tire Size and Construction

	Transaxle	Metric Measure	U.S. Measure
P185 75 R14		19 Yellow	
P195 75 R14		19 Yellow	
P205 70 R14		19 Yellow	
P215 60 R15		19 Yellow	
P195 70 R14		19 Yellow	
All other original equipment tires		19 Blue	

A-525/A-520/A-555 MANUAL TRANSAKLE FLUID FILL

Fill All Manual Transaxes with SAE 5W-30 Engine oil to bottom of fill hole in end cover:

Transaxle	Metric Measure	U.S. Measure
A-525	2.1 Liters	2.3 Quarts
A-520/A-555	2.3 Liters	2.5 Quarts



Technical Service Information



Technical Service Information





INCHES TO MILLIMETERS

All values in this table are exact

	0.000	0.001	0.002	0.003	0.004	0.005	0.006	0.007	0.008	0.009
	millimeters									
0.000	0.0254	0.0508	0.0752	0.1016	0.1270	0.1524	0.1778	0.2032	0.2286	0.2540
0.010	0.2540	0.2794	0.3048	0.3302	0.3556	0.3810	0.4064	0.4318	0.4572	0.4826
0.020	0.5080	0.5334	0.5588	0.5842	0.6096	0.6350	0.6604	0.6858	0.7112	0.7366
0.030	0.7620	0.7874	0.8128	0.8382	0.8636	0.8890	0.9144	0.9398	0.9652	0.9906
0.040	1.0160	1.0414	1.0668	1.0922	1.1176	1.1430	1.1684	1.1938	1.2192	1.2446
0.050	1.2700	1.2954	1.3208	1.3462	1.3716	1.3970	1.4224	1.4478	1.4732	1.4986
0.060	1.5240	1.5494	1.5748	1.6002	1.6256	1.6510	1.6764	1.7018	1.7272	1.7526
0.070	1.7780	1.8034	1.8288	1.8542	1.8795	1.9050	1.9304	1.9558	2.0062	2.0466
0.080	2.0320	2.0574	2.0828	2.1082	2.1336	2.1590	2.1844	2.2098	2.2352	2.2606
0.090	2.2860	2.3114	2.3368	2.3622	2.3876	2.4130	2.4384	2.4638	2.4892	2.5146
0.100	2.5400	2.5654	2.5908	2.6162	2.6416	2.6670	2.6924	2.7178	2.7432	2.7686
0.110	2.7940	2.8194	2.8448	2.8702	2.8956	2.9210	2.9464	2.9718	2.9972	3.0226
0.120	3.0480	3.0734	3.0888	3.1242	3.1496	3.1750	3.2004	3.2258	3.2512	3.2766
0.130	3.3020	3.3274	3.3528	3.3782	3.4036	3.4290	3.4544	3.4798	3.5056	3.5306
0.140	3.5560	3.5814	3.6068	3.6322	3.6576	3.6830	3.7084	3.7338	3.7592	3.7846
0.150	3.8100	3.8354	3.8608	3.8862	3.9116	3.9370	3.9624	3.9878	4.0132	4.0386
0.160	4.0640	4.0894	4.1148	4.1402	4.1656	4.1910	4.2164	4.2418	4.2672	4.2926
0.170	4.3180	4.3434	4.3688	4.3942	4.4196	4.4450	4.4704	4.4958	4.5212	4.5466
0.180	4.5720	4.6228	4.6582	4.6936	4.7290	4.7544	4.7798	4.8052	4.8306	4.8560
0.190	4.8260	4.8514	4.8768	4.9022	4.9376	4.9630	4.9884	5.0038	5.0292	5.0456
0.200	5.0800	5.1054	5.1308	5.1562	5.1816	5.2070	5.2324	5.2578	5.2832	5.3086
0.210	5.3340	5.3594	5.3848	5.4102	5.4356	5.4610	5.4864	5.5118	5.5372	5.5626
0.220	5.5880	5.6134	5.6388	5.6642	5.6896	5.7150	5.7404	5.7658	5.7912	5.8166
0.230	5.8420	5.8674	5.8928	5.9182	5.9436	5.9690	5.9944	6.0198	6.0352	6.0606
0.240	6.0960	6.1214	6.1468	6.1722	6.1976	6.2230	6.2484	6.2738	6.2992	6.3246
0.250	6.3500	6.3754	6.4008	6.4262	6.4516	6.4770	6.5024	6.5278	6.5532	6.5786
0.260	6.6040	6.6294	6.6548	6.6802	6.7056	6.7310	6.7564	6.7818	6.8072	6.8326
0.270	6.8580	6.8834	6.9088	6.9342	6.9596	6.9850	7.0104	7.0358	7.0612	7.0866
0.280	7.1120	7.1374	7.1628	7.2136	7.2390	7.2644	7.2989	7.3152	7.3406	7.3660
0.290	7.3660	7.3914	7.4168	7.4422	7.4676	7.4930	7.5184	7.5438	7.5692	7.5946
0.300	7.6200	7.6454	7.5708	7.6962	7.7216	7.7470	7.7724	7.7978	7.8232	7.8486
0.310	7.8740	7.8994	7.9248	7.9502	7.9756	8.0010	8.0264	8.0518	8.0772	8.1026
0.320	8.1280	8.1534	8.1788	8.2042	8.2296	8.2560	8.2814	8.3068	8.3312	8.3566
0.330	8.3820	8.4074	8.4328	8.4582	8.4836	8.5090	8.5344	8.5598	8.5852	8.6106
0.340	8.6360	8.6614	8.6868	8.7122	8.7376	8.7630	8.7884	8.8138	8.8392	8.8646
0.350	8.8900	8.9154	8.9408	8.9662	8.9916	9.0170	9.0424	9.0678	9.0932	9.1186
0.360	9.1440	9.1694	9.1948	9.2202	9.2456	9.2710	9.2964	9.3218	9.3472	9.3726
0.370	9.3980	9.4234	9.4488	9.4742	9.4996	9.5250	9.5504	9.5758	9.6012	9.6266
0.380	9.6520	9.6774	9.6928	9.7182	9.7436	9.7790	9.8044	9.8298	9.8552	9.8806
0.390	9.9060	9.9314	9.9568	9.9822	10.0076	10.0330	10.0584	10.0838	10.1092	10.1346
0.400	10.1600	10.1854	10.2108	10.2362	10.2616	10.2870	10.3124	10.3378	10.3632	10.3886
0.410	10.4140	10.4394	10.4648	10.4902	10.5156	10.5410	10.5664	10.5918	10.6172	10.6426
0.420	10.6680	10.6934	10.7188	10.7442	10.7696	10.7950	10.8204	10.8458	10.8712	10.8966
0.430	10.9220	10.9474	10.9728	10.9982	11.0236	11.0490	11.0744	11.0998	11.1252	11.1506
0.440	11.1226	11.1228	11.1252	11.1276	11.1303	11.1328	11.1353	11.1379	11.1404	11.1436
0.450	11.4300	11.4554	11.4808	11.5062	11.5316	11.5570	11.5824	11.6078	11.6332	11.6586
0.460	11.6840	11.7094	11.7356	11.7602	11.7856	11.8110	11.8364	11.8618	11.9126	11.9582
0.470	11.934	11.9584	12.0142	12.0396	12.0650	12.0904	12.1156	12.1412	12.1666	12.1920
0.480	12.1920	12.2174	12.2428	12.2682	12.2936	12.3190	12.3444	12.3698	12.3952	12.4204
0.490	12.4450	12.4714	12.4968	12.5222	12.5476	12.5730	12.5984	12.6238	12.6492	12.6746




Fig. 7—#1 Caged Needle Bearing

Fig. 4—Remove Oil Pump







Technical Service Information



Technical Service Information



GENERAL RULES ON SERVICING BEARINGS

BEARING ADJUSTMENT PROCEDURES

(1) Take extreme care when removing and installing bearing cups and cones. Use only an arbor press for installation, as a hammer may not properly align the bearing cup or cone. Burrs or nicks on the bearing seat will give a false end play reading, while gauging for proper shims.

Improperly seated bearing cup and cones are subject to low-mileage failure.

(2) Bearing cups and cones should be replaced if they show signs of pitting or heat distress.

If distress is seen on either the cup or bearing rollers, both cup and cone must be replaced. Bearing end play and drag torque specifications must be maintained to avoid premature bearing failures.

Used (original) bearing may lose up to 50% of the original drag torque after break-in. All bearing adjustments must be made with no other component interference or gear inter-mesh, except the transfer gear bearing.

OUTPUT GEAR BEARINGS

The output gear tapered roller bearings must have a preload of .02 to .05 millimeter (.0008 to .002 inch).

DIFFERENTIAL BEARING

- (1) Remove the bearing cup from the differential bearing retainer using Tool L-4510, and remove the existing shim from under the cup.
 - (2) Install a .30 mm (.0120 inch) gauging shim and reinstall the bearing cup into the retainer. Use an arbor press to install the cup.
- Oil Baffle** is not required when making shim selection.

DIFFERENTIAL BEARING SHIM CHART

mm. Inch	mm	Required Shim Combination	Total Thickness
.0	.0		.020
.05	.002	.50	.50
.10	.004	.75	.75
.15	.006	.85	.85
.20	.008	.90	.90
.25	.010	.95	.95
.30	.012	1.00	.939
.35	.014	1.05	.939
.40	.016	.80	.930
.45	.018	.60	.932
.50	.020	.60	.934
.55	.022	.70	.934
.60	.024	.80	.945
.65	.026	.85	.945
.70	.027	.90	.945
.75	.029	.95	.945
.80	.031	1.00	.957
.85	.033	.50 + 1.05	.959
.90	.035	.50 + 1.05	.961
.95	.037	1.00 + .65	.963
1.00	.039	1.00 + .70	.965
1.05	.041	.75	.967
1.10	.043	.80	.969
1.15	.045	.85	.971
1.20	.047	.90	.973
1.25	.049	1.00 + .95	.975
1.30	.051	1.00 + .70	.977
1.35	.053	1.00 + .80	.979
1.40	.055	1.00 + .85	.981



Technical Service Information




Fig. 24—Low/Reverse Clutch Pack




Fig. 25—Rear Cover Bolts




Fig. 26—Rear Cover




Fig. 27—Remove Transfer Shaft Gear Nut





Fig. 28—Transfer Shaft Gear Nut and Washer




Fig. 19—Differential Gears




Fig. 20—Checking Side Gear End Play




Fig. 21—Checking Side Gear End Play

CAUTION: Side gear end play must be within .001 to .013 inch.

4 select thrust washers are available: .032, .037, .042, and .047 inch.

CAUTION: Side gear end play must be within .001 to .013 inch.

4 select thrust washers are available: .032, .037, .042, and .047 inch.




Fig. 22—Remove Oil Seal




Fig. 23—Install New Oil Seal



Technical Service Information



Technical Service Information



Technical Service Information




Fig. 36—Remove Transfer Shaft Bearing Cup




Fig. 39—Transfer Shaft




Fig. 37—Install New Bearing Cup




Fig. 40—Remove Transfer Shaft Bearing Cone

Fig. 38—Transfer Shaft Bearing Snap Ring

Fig. 41—Install Bearing Cone




Fig. 9—Remove or Install Extension




Fig. 7—Differential Bearing Retainer




Fig. 10—Differential and Extension




Fig. 11—Remove Differential Bearing Cone

Fig. 12—Install Differential Bearing Cone



Technical Service Information




Fig. 47—Output Gear and (Select) Shim




Fig. 32—Install #2 Needle Bearing




Fig. 35—Install #3 Thrust Plate




Fig. 48—Remove Bearing Cone




Fig. 50—Rear Carrier Assembly




Fig. 49—Install New Bearing Cone




Fig. 34—Install #3 Thrust Washer




Fig. 37—Input Shaft Clutches Assembly

Now that both shaft assemblies and thrust washers are properly installed, reinstall overdrive clutch and reverse clutch as shown in Figure 21 thru 29. Rechecking these clutch clearances is not necessary, as they were set and approved previously.



Technical Service Information




Fig. 33—Install Underdrive Shaft Assembly




Fig. 36—Install Overdrive Shaft Assembly



Technical Service Information




Fig. 59—Guide Bracket Pivot Shaft




Fig. 60—Pivot Shaft and Guide Bracket




Fig. 61—Guide Bracket Assembled




Fig. 62—Guide Bracket Disassembled




Fig. 63—Low/Reverse Clutch Piston




Fig. 64—Piston Retainer Attaching Screws



Technical Service Information



Fig. 21—Install OD Clutch Pack




Fig. 24—Pressure Plate Installed




Fig. 22—Install Waved Snap Ring




Fig. 23—OD/Reverse Pressure Plate




Fig. 25—Install Flat Snap Ring









Fig. 26—Check OD Clutch Pack Clearance

The overdrive (OD) clutch pack clearance is .042 to .095 inch. If not within specifications, the clutch is not assembled properly. There is no adjustment for the OD clutch clearance.



Technical Service Information



DETERMINING #4 THRUST PLATE THICKNESS (Input Shaft End Play) (Figs. 73, 74, 75, and 76)



Press down clutch pack with finger and zero dial indicator. Low/Reverse clutch pack clearance is 1.04 to 1.55mm (.042 to .065 inch). Select the proper low/reverse reaction plate to achieve specifications:

PART NO.	Thickness
4377150	6.92 mm (.273 in.)
4377149	6.65 mm (.262 in.)
4377148	6.40 mm (.252 in.)
4412268	6.14 mm (.242 in.)
4412267	5.88 mm (.232 in.)
4412266	5.62 mm (.221 in.)
4412265	5.36 mm (.211 in.)

To determine the proper thickness of the #4 thrust plate, select the thinnest #4 thrust plate. Using petrolatum (Fig. 73) to hold thrust plate in position, install input clutches retainer. Be sure the input clutches retainer is completely seated (Fig. 74).

Fig. 74—View Through Input Speed Sensor Hole



CAUTION: If view through input speed sensor hole is not as shown above, the input clutches assembly is not seated properly.



Press down clutch pack with finger and zero dial indicator. The 2/4 clutch pack clearance is 0.76 to 2.6mm (.030 to 1.04 inch). If not within specifications, the clutch is not assembled properly. There is no adjustment for the 2/4 clutch clearance.



Technical Service Information



CAUTION: DO NOT REUSE TAPERED SNAP RING.

Fig. 13—UD Clutch Flat Snap Ring









Fig. 16—Tapered Snap Ring



Technical Service Information

SUBASSEMBLY RECONDITION








Input Shaft Clutches Retainer Assembly Disassembly



Technical Service Information

SUBASSEMBLY RECONDITION

Input Shaft Clutches Retainer Assembly





Technical Service Information

























Fig. 14—OD/UD Reaction Plate Tapered Snap Ring

Fig. 15—Tapered Snap Ring Instructions

Fig. 19—UD Clutch Pack

Fig. 20—UD Spring Retainer Snap Ring

Fig. 21—UD Return Spring and Retainer

Fig. 22—Underdrive Clutch Piston

Technical Service Information

